



- 1** Hour | Stunde
- 2** Minute | Minute
- 3** Stopwatch seconds | Stoppuhr Sekunden
- 4** Stopwatch hours | Stoppuhr Stunden
- 5** Stopwatch minutes | Stoppuhr Minuten
- 6** Second | Sekunde
- 7** Normal position | Normalposition
- 8** Time setting | Zeiteinstellung
- A** Button A | Taste A | stop | Start
- B** Button B | Taste B | reset | Rücksetzung

Battery | Batterie

SR927SW

Movement | Uhrwerk

Citizen-Miyota 0S30

Case thickness | Gehäusehöhe

11,7 mm

Circumference | Umfang

Adjustable length | Größenverstellbar

Weight | Gewicht

135 g

Glass | Glas

Hardened mineral crystal | Mineralglas

Backplate | Rückseite Gehäuse

Metal | Metall

Water resistance | Wassersäule

Splash-proof | Spritzwasserfest

Band width | Armbandbreite

22,2 mm

Band | Armband

Metal, wood | Metall, Holz

Screws | Schrauben

Stopwatch

This watch includes a stopwatch function which you can start and stop by pressing button A, and reset with button B.

You can adjust the second hand when using the stopwatch function by pulling the crown out two clicks (until the clock stops), then use button A to adjust the hand.

Stoppuhr

In diesem Modell ist eine Stoppuhr integriert, welche sich mit der Taste A starten und anhalten und mit der Taste B zurückstellen lässt.

Den Sekundenzeiger der Stoppuhr kannst du einstellen, indem du die Krone 2x herausziehst bis die Uhr komplett stillsteht. Nun kannst du mit der Taste A den Zeiger verstellen.

Instructions Band
Anleitung Armband

 EN: www.holzkern.com/en/faq/#size

 DE: www.holzkern.com/de/faq/#size

Accuracy/Month
Genauigkeit/Monat

 ± 20 sec.
 ± 20 Sek.

Battery life
Batterie Lebensdauer

 2 Years
 2 Jahre