



- 1** Hour | Stunde
- 2** Minute | Minute
- 3** Second | Sekunde
- 4** Day hand | Tagesanzeige
- 5** Dual time 24-hour hand | Dual-Time 24-Stundenzeiger
- 6** 24-hour hand | 24-Stundenzeiger
- 7** Date | Datum
- 8** Normal position | Normalposition
- 9** 1st click | 1. Position
- 10** 2nd click | 2. Position
- A** Button A | Taste A
- B** Button B | Taste B

Battery | Batterie

CR2012

Movement | Uhrwerk

Citizen-Miyota JP75

Circumference | Umfang

Adjustable length | Größenverstellbar

Glass | Glas

Hardened mineral crystal | Mineralglas

Backplate | Rückseite Gehäuse

Metal, glass | Metall, Glas

Water resistance | Wassersäule

Splash-proof | Spritzwasserfest

Band | Armband

Metal, wood | Metall, Holz

**Instructions Band
Anleitung Armband**

EN: www.holzkern.com/en/faq/#size

DE: www.holzkern.com/de/faq/#size

Setting the time, day and date

You can adjust the time by turning the crown in position two.

In position one you can adjust the date by turning the crown clockwise.*

To set the day, turn the crown clockwise in position 2 until the hand indicates the correct day.

*Don't set the date between 21:00 and 01:00 (the date may not change the next day).

Setting dual time

With the crown in normal position, you can correct the dual time with the buttons A and B by +/- 15 minutes.

Uhrzeit, Tag und Datum einstellen

Du kannst an der 2x herausgezogenen Krone durch Drehen die korrekte Uhrzeit einstellen.

Bei 1x herausgezogener Krone kannst du durch Drehen im Uhrzeigersinn das Datum einstellen.*

Um den Tag einzustellen, drehe die Krone in Position 2 so lange im Uhrzeigersinn, bis der Zeiger den richtigen Tag anzeigt.

*Stelle das Datum nicht zwischen 21:00 und 01:00 Uhr ein (das Datum stellt sich sonst am nächsten Tag nicht richtig um).

Dual-Time einstellen

In Normalposition kannst du die Dual-Time-Anzeige mit den Tasten A und B um +/- 15 Minuten korrigieren.



Accuracy/Month ± 20 sec.
Genauigkeit/Monat ± 20 Sek.



Battery life 8 Years
Batterie Lebensdauer 8 Jahre