



- 1** Hour | Stunde
- 2** Minute | Minute
- 3** Stopwatch seconds | Stoppuhr Sekunden
- 4** Stopwatch minutes | Stoppuhr Minuten
- 5** Second | Sekunde
- 6** Date | Datum
- 7** Normal position | Normalposition
- 8** 1st click: date setting | 1. Position: Datum einstellen
- 9** 2nd click: time setting | 2 Position: Zeiteinstellung
- A** Button A | Taste A | stop | Start
- B** Button B | Taste B | reset | Rücksetzung

**Battery | Batterie**

SR927SW

**Movement | Uhrwerk**

Citizen-Miyota OS11

**Case thickness | Gehäusehöhe**

11 mm

**Circumference | Umfang**

Adjustable length | Größenverstellbar

**Weight | Gewicht**

103 g

**Glass | Glas**

Hardened mineral crystal | Mineralglas

**Backplate | Rückseite Gehäuse**

Metal | Metall

**Water resistance | Wassersäule**

Splash-proof | Spritzwasserfest

**Band width | Armbandbreite**

18 mm

**Band | Armband**

Metal, wood | Metall, Holz

Screws | Schrauben

**Stopwatch**

This watch includes a stopwatch function which you can start and stop by pressing button A, and reset with button B.

You can adjust the second hand when using the stopwatch function by pulling the crown out two clicks (until the clock stops), then use buttons A and B to adjust the hand.

**Stoppuhr**

In diesem Modell ist eine Stoppuhr integriert, welche sich mit der Taste A starten und anhalten und mit der Taste B zurückstellen lässt.

Den Sekundenzeiger der Stoppuhr kannst du einstellen, indem du die Krone 2x herausziehst bis die Uhr komplett stillsteht. Nun kannst du mit den beiden Tasten A und B den Zeiger verstellen.

**Instructions Band**  
**Anleitung Armband**

 EN: [www.holzkern.com/en/faq/#size](http://www.holzkern.com/en/faq/#size)

 DE: [www.holzkern.com/de/faq/#size](http://www.holzkern.com/de/faq/#size)


**Accuracy/Month**    ± 20 sec.  
**Genauigkeit/Monat**    ± 20 Sek.



**Battery life**    2 Years  
**Batterie Lebensdauer**    2 Jahre