


GMT Cloudhopper

41mm

EN | DE



- 1** Hour | Stunde
- 2** Minute | Minute
- 3** Second | Sekunde
- 4** GMT
- 5** Date | Datum
- 6** Bezel | Lünette
- 7** Normal position | Normalposition
- 8** 1st click | 1. Position
- 9** 2nd click | 2. Position
- 10** Normal position | Normalposition
- 11** 1st click | 1. Position

**Automatic movement |
Automatikuhrwerk**
Seiko NH34

Case thickness | Gehäusehöhe
13 mm

Circumference | Umfang
Adjustable length | Größenverstellbar

Weight | Gewicht
96 g

Band width | Armbandbreite
24 mm

Water resistance | Wassersäule
Splash-proof | Spritzwasserfest

Glass | Glas
Sapphire glass | Saphirglas

Caseback | Rückseite Gehäuse
Metal, Mineral glass | Metall, Mineralglas

Band | Armband
Leather | Leder

Case connection | Gehäuseverbindung
Spring pin with lever | Federstift mit Hebel

Luminescent | Lumineszierend
Hands | Zeiger



Accuracy/Day ±20 sec.
Genauigkeit/Tag ±20 Sek.



Running time 42 Hours
Laufzeit 42 Stunden

Winding the watch

Wind the movement by turning the crown clockwise 40 times prior to wearing it. The movement will also wind automatically through regular use; however, after many hours without being worn it may be necessary to wind the movement again.

Setting the time

To adjust the date pull the crown out to the first click. Then turn the crown clockwise until the previous day's date* appears. After this pull out the crown to the second click** when the second hand is at position 12:00. It will stop on the spot. Then set the hands to the desired time of the day (make sure AM/PM is set correctly) by turning the crown.

After setting the correct time, push the crown back in the normal position.

*Don't set the date between 21:00 and 01:00 (the date may not change the next day). If it is necessary to set the date during that time period, firstly change the time to any time outside, set the date and then reset to the correct time.

**When the crown is at the second click position, do not press any button. Otherwise the chronograph hands will move.

Setting three Time Zones

For example if you want to track the time in New York, GMT, and Tokyo.

Set Local Time:

You can adjust the time by turning the crown (7) in position one (9) and set it to New York time (e.g., 7:00 AM).

Set GMT Time:

You can adjust the time by turning the crown (10) in position one (11). Set the GMT (4) hand to current GMT time (e.g., 12:00 PM GMT).

Set the Bezel for a Third Time Zone:

For a time zone ahead of GMT (Tokyo):

Rotate the bezel (6) clockwise by the number of hours ahead.

For example, Tokyo is 9 hours ahead of GMT, so you rotate the bezel 9 hours forward from the GMT hand.

For a time zone behind GMT (New York):

Rotate the bezel (6) counterclockwise by the number of hours behind.

For example, New York is 5 hours behind GMT, so you rotate the bezel 5 hours back from the GMT hand.

Uhr aufziehen

Drehe die Krone 40 Mal im Uhrzeigersinn, bevor du deine Uhr zum ersten Mal anlegst und sie beginnt zu laufen. Das Uhrwerk zieht sich nun durch deine Bewegung selbstständig auf. Sollte die Uhr mehr als 40 Stunden nicht getragen werden, wiederhole den Vorgang.

Uhrzeit einstellen

Das Datum kannst du einstellen indem du die Krone in Position 1 im Uhrzeigersinn bis zum gewünschten Datum* drehst. Dann kannst du die Krone in Position 2** herausziehen, wenn der Sekundenzeiger bei 0 steht. Dann kannst du durch das Drehen der Krone die gewünschte Uhrzeit einstellen (stellen Sie sicher, dass AM/PM richtig eingestellt ist). Nach dem Einstellen der korrekten Uhrzeit drückt die Krone wieder in die normale Position.

*Stelle das Datum nicht zwischen 21:00 und 01:00 Uhr ein (das Datum stellt sich sonst am nächsten Tag nicht richtig um). Falls es notwendig ist, das Datum während dieses Zeitraums einzustellen, stelle zuerst die Uhrzeit auf eine beliebige Zeit außerhalb des Zeitraums ein, dann stelle das Datum ein und danach wieder die korrekte Uhrzeit.

Drei Zeitzonen einstellen

Wenn du beispielsweise die Zeit in New York, GMT und Tokio verfolgen möchtest.

Ortszeit einstellen:

Du kannst die Uhrzeit anpassen, indem du die Krone (7) in Position eins (9) drehst und auf New Yorker Zeit (z. B. 7:00 Uhr) einstellst.

GMT-Zeit einstellen:

Du kannst die Uhrzeit einstellen, indem du die Krone (10) in Position eins (11) drehst. Stelle den GMT-Zeiger (4) auf die aktuelle GMT-Zeit ein (z. B. 12:00 Uhr GMT).

Stelle die Lünette auf eine dritte Zeitzone ein:

Für eine Zeitzone auf GMT (Tokio):

Drehe die Lünette (6) um die Anzahl der Stunden im Uhrzeigersinn.

Tokio ist beispielsweise 9 Stunden vor GMT, also drehe die Lünette vom GMT-Zeiger aus 9 Stunden nach vorne.

Für eine Zeitzone hinter GMT (New York):

Drehe die Lünette (6) um die Anzahl der zurückliegenden Stunden gegen den Uhrzeigersinn.

New York liegt beispielsweise 5 Stunden hinter GMT, also drehe die Lünette vom GMT-Zeiger um 5 Stunden zurück.

Wenn du beispielsweise die Zeit in New York, GMT und Tokio verfolgen möchtest.

Instructions Strap | Anleitung Armband

EN: www.holzkern.com/en/faq/#size | DE: www.holzkern.com/de/faq/#size